

USER MANUAL - LM1

1. Product Description:

LOKUKA Bluetooth Transmitter is designed to add Bluetooth to old devices and transfer audio. It has two modes:

- (1) TX Mode: Seamlessly transmit audio from in-flight entertainment, gym equipment, gaming devices, TVs, or any 3.5mm audio jack to your earbuds, or wireless headphones without the hassle of cords.
- (2) RX Mode: LOKUKA USB to 3.5mm Bluetooth car audio adapter is easy to use. Simply connect it to the Aux port of your car stereo, speaker, amplifier, headphone, or any other audio device, then turn on the phone Bluetooth and connect the "M28". LOKUKA aux Bluetooth adapter supports music, hands-free calls, voice navigation, etc.



2. Product Specifications:

Bluetooth name	M28
Size	12x2.5x1.7CM
Material	ABS
Version	BT 5.3
Wireless distance	approximately 15M
Battery capacity	200mAh
Working time	approximately 6 hours
Charging duration	approximately 1.5 hours

3. Product Analysis:



4. User Guide:



How to connect in TX mode?

Step 1:

Insert the M28 audio cable into the player that needs to transmit audio (such as a TV, computer, airplane, projector, etc.)

Step 2:

Turn on the Bluetooth earphones/speakers and adjust them to the pairing waiting state.

Step 3:

Switch to TX mode (red light). Press the side round power button for 1.5s. The M28 will automatically connects to your Bluetooth earphones/speakers. (When powered, the red light flashes quickly and turns into a slow flash when the Bluetooth "M28" connects successfully.)

Step 4:

Start the music on your devices and it will play on your speaker/headphone.



How to connect in RX mode?

Step 1:

Switch to RX mode (blue light). Press the side round power button for 1.5s.

Step 2:

Searching for M28 on your phone/tablet/computer, and click it to connect.

Step 3:

Insert the 3.5mm plug into the AUX input port of the speaker/headphones /car "AUX IN".

Step 4:

Start the phone music and it will play on your speaker/headphone/car.

5. Packaging list:

Wireless adapter x1
Type-c charging cable x1
Instructions x1

24/7 CUSTOMER SERVICE

1. Unconditional 30-Day Refund or Replacement:

Not satisfied with this purchase? Return or replace it within 30 days of purchase on Amazon.

2. Premium Warranty Policy:

All LOKUKA products have a 12-Month unconditional warranty to guard against any quality issues. You can also apply to extend it to 18 months for free.

3. Extend Your Warranty to 18 Months?

Email: your order ID and keywords "18 months warranty"

To: support@lokuka.com

4. Need Help with This Purchase?

Contact our 24-hour customer support team to get help via support@lokuka.com

5. HAPPY with This Purchase?

Welcome to share your experience on the product page!

6. 24-hour Free Online Q&A

LOKUKA offers lifetime technical support for all customers who reached us. If you have any audio cable related questions, please email us freely!

SAFETY INFORMATION

- 1. Use for original or certified devices or accessories only.
- 2. Avoid improper bending, twisting, or abuse of the cable.
- 3. Avoid extreme temperatures, sun exposure, wet environment, or any hazardous surroundings.
- 4. Prodcut should be placed well to avoid tripping or other potential safety hazards.

HOW TO CONTACT US?

